

		level switch ⑦ Inspection and cleaning of water injection nozzle in pyrite box ⑧ Filling up of grease to hinge parts of all access doors on middle housing ⑨ Inspection, repair and cleaning of seal ring for supporting shell ⑩ Adjustment of length of tie rod seal expansion joint	
--	--	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--

TABLE 9.1 Maintenance Schedule for Pulverizer(3/4)

NO .	Inspection Interval	Items	Countermeasures
		⑪ Replacement of the magnet plug on roll wheel ⑫ Maintenance of hydraulic cylinder ⑬ Replacement of the fixing plate for the spherical bearings ⑭ Maintenance of pyrite plow Replacement of roller tire, if requiredent of spray nozzle for the pyrite	
4.	Every 16,000 operating hour	① Replacement of Yoke cover and cover cone ② Replacement of wearing plate of pyrite plow ③ Replacement of wearing plate of roller bracket (lower wearing plate) ④ Replacement of wearing plate of between loading frame and mill housing (loaded side and un-loaded side) ⑤ Replacement of spherical bearings for tie rod and its fixing sleeve ⑥ Protector for loading parts	