

Woodward Governor Digital Modules & Miscellaneous Parts	
Part Number	Description
5462-450	301 Seq Master CPU Module
5462-460	DCS II Master CPU Module
5462-472	Woodward Board/Module
5462-482	Woodward Board/Module
5462-509	DCS II SIO Version 3.0 Module
5462-518	Speed Sensor
5462-519	Speed Control
5462-520	Speed Reference
5462-521	Power Sensor
5462-522	Power Control
5462-523	Power Reference
5462-524	Extraction Control
5462-525	Pressure Preference
5462-526	Ratio Limiter
5462-527	Valve Ramp
5462-528	Final Driver
5462-529	Valve Ramp
5462-530	Final Driver
5462-531	Auxiliary
5462-532	Pressure Channel
5462-533	Power Preference
5462-537	CPU Module
5462-574	DCS II Aux Memory Sub Mod
5462-578	High Volt Power Supply
5462-581	Woodward Board/Module
5462-584	DCS Motherboard
5462-599	Transient Load Sensor Module
5462-614	Final Driver Module
5462-636	CPU Module
5462-640	SIO Module

Woodward Governor Digital Modules & Miscellaneous Parts	
Part Number	Description
5462-645	CPU Module
5462-651	Analog 8 Channel 4-20mA Input
5462-652	Woodward Board/Module
5462-718	Speed Sensor
5462-736	CPU Module
5462-740	CPU Module
5462-748	CPU Module
5462-749	Auxiliary CPU (Ref: 5463-192)
5462-750	Secondary Power Supply – 501
5462-753	Woodward Board/Module
5462-756	301 Seq Master CPU Module
5462-757	28 Channel Discrete Input Mod.
5462-758	28 Chan. Discrete Output Mod.
5462-760	DCS Pos. Transducer Mod.
5462-762	SIO Card
5462-767	DCS II Discrete Input Module
5462-780	Woodward Board/Module
5462-793	CPU Module
5462-795	CPU Module
5462-882	Woodward Board/Module
5462-892	SIO Module
5462-893	CPU Module
5462-896	CPU Module
5462-916	FTC Module – DCS II
5462-917	CPU Module with Chips 9929-453B & 5410-476A
5462-923	CPU Module
5462-942	SIO Module
5462-943	CPU Module
5462-944	DCSII- DPS3/DT Module

Woodward Governor Digital Modules & Miscellaneous Parts	
Part Number	Description
5462-948	T/C Card- 8 Channel
5462-950	DCS Pos. Transducer Module
5462-952	DCS Pos. Transducer Module
5462-958	501 Master CPU Module
5462-959	8 Chan. RTD 10/100 Mod.
5462-960	CPU Module
5462-961	CPU Module
5462-966	Module
5462-980	CPU Module
5462-981	DCS II Aux Memory Sub Mod.
5463-009	LVDT Pos. Transducer Module
5463-031	DCSII 4 Channel Module
5463-033	Power Aux N.O. Module
5463-034	Power Aux. N.C.
5463-089	CPU Module
5463-094	8 Channel 10 OHM RTD Mod.
5463-109	DCS Transcvr Exp Chas Mod.
5463-119	301 Seq. Master CPU Module
5463-120	CPU Module
5463-121	NetCon 5000 Memory
5463-124	SIO Module
5463-127	SIO Module
5463-128	Woodward Board/Module
5463-140	Master CPU
5463-141	Master CO CPU
5463-143	Aux Memory Module
5463-151	Aux Memory Module
5463-154	Discrete Input/Output Module
5463-176	Power Aux NC Module
5463-177	Power Aux NO Module