


Section 7

ILLUSTRATIONS AND PARTS LIST

7.7 COMPRESSOR COOLING AND LUBRICATION SYSTEM (AIR-COOLED, LS-12 SERIES 40 AND 50HP)



Section 7

ILLUSTRATIONS AND PARTS LIST

7.7 COMPRESSOR COOLING AND LUBRICATION SYSTEM (AIR-COOLED, LS-12 SERIES 40 AND 50HP) (CONTINUED)

<i>key number</i>	<i>description</i>	<i>part number</i>	<i>quantity</i>
33	tubing, thermosplastic 3/8"od	250024-746	1 ft.
34	tube, 1 1/2"	250018-252	1
35	bushing, reducing 2" x 1 1/2"	802108-060	1
36	coupling, pipe 1/2"	801215-020	1
37	bracket, separator trap	250018-378	1
38	coupling, reducing 2" x 1 1/2"	801016-012	1
39	separator/trap (IV)	040847	1
40	tube, 1"	250018-245	1
41	connector, tube elbow 3/8"tube x 1/2"npt	813706-375	2
42	elbow, 1 1/2" x 1 1/4" reducing	801606-050	1
43	nipple, pipe 1 1/2" x 7 1/2"	822124-075	1
44	elbow, pipe 90_ 1 1/2"	801515-060	1

(IV) For maintenance on separator/trap no. 040847, order separator kit no. 044374.

PLEASE NOTE: WHEN ORDERING PARTS, ALWAYS INDICATE SERIAL NUMBER OF COMPRESSOR.