


# **FGD Louver Dampers**



## FIELD ASSEMBLY, OPERATION & MAINTENANCE MANUAL

### 6.4. RECOMMENDED SPARE PARTS

### Spare Parts – Startup and Commissioning (for unit 1&2)

	Unit of		
Description	Measure	Quantity	Wear or Strategic
Replacement Blade Seals, C276	meters	10	S
Replacement Frame Seals, C276	meters	5	S
Linkage arm (rod ends)	ea	2	S
Boom Roller	ea	2	W
Solenoid Coil	ea	1	S

#### Spare Parts – 2 to 5 Years

Unit of		
Measure	Quantity	Wear or Strategic
meters	8	W
meters	8	W
sets	24	S
ea	1	S
ea	1	S
ea	1	W
sets	2	S
ea	1	S
	meters meters sets ea ea sets	MeasureQuantitymeters8meters8sets24ea1ea1sets2